




# 3

## D-Link ANT24-0401 Ceiling Mount Antenna

Remove one default antenna from the wireless device and start to assemble!




Horizontal coverage



Vertical coverage

### Installation Note:

1. Carefully remove the antenna from the package.
2. Take out the Washer ( 1 pcs ) from the package
3. Take out the Flange washer ( 1 pcs ) as well.
4. Drill 2 holes through the ceiling board, one to fix the antenna main body with washer, another for the antenna SMA connector linked onto extension cable which is included within the package.



Frequency band	2400-2500MHz
Antenna gain	2.5 ~ 3.7 dBi
VSWR	2.0 max
Polarization	Linear vertical
HPBW / H-plane	360°
HPBW / E-plane	50 ~ 75 °
Impedence	50 Ohms
Dimensions	∅132x42 mm
Weight	110g without joint

### Package Contents:

- ANT24-0401 Antenna
- Extension Cable ( 2M )
- Mounting Kit
- Quick Installation Guide