

Remove one default antenna from the wireless device and start to assemble!





Installation:

- 1. Remove the original antenna from your wireless device.
- 2. Screw the DWL-R60AT RP- SMA connector into your wireless device.
- 3. Adjust the antenna to the suitable direction for extending the wireless coverage area.

Frequency band	2400-2500MHz
Antenna gain	6.0dBi Typical
VSWR	2.0:1 Max.
Polarization	Linear
HPBW / H-plane	90°
HPBW / E-plane	75°
Impedence	50 Ohms nominal
Dimensions HxWxD	80x85x12.8 mm
Weight	75gw

Package Contents:

- DWL-R60AT Antenna
- Quick Installation Guide