





<b>DWL-2200AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-2210AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-3200AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-5000AP</b>												
<b>DWL-6000AP</b>												
<b>DWL-7000AP</b>												
<b>DWL-700AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-7100AP</b>												
<b>DWL-7200AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-800AP+</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-8200AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-900AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-900AP+</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-AG700AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>DWL-G700AP</b>	X	X	X	X	X	X	X	X	X	X	X	X
<b>Points d'Accès Extérieur Wireless</b>												
<b>DWL-1700AP</b>								X*		X*	X*	X*
<b>DWL-1750</b>								X*		X*	X*	X*
<b>DWL-2700AP</b>								X*		X*	X*	X*
<b>DWL-7700AP</b>								X*		X*	X*	X*
<b>Hot Spot</b>												
<b>DSA-3200</b>	X	X	X	X	X	X	X	X	X	X	X	X

- un câble additionnel d'extension de type ANT24-CBxxN est nécessaire.